





PROTEC[®] COOLING TOWERS, INC.

ENERGY - EFFICIENT COOLING TOWERS



OPERATING AND MAINTENANCE MANUAL



F-OM 9/00



Member of
Cooling Tower Institute

* Logo of the Cooling Tower Institute

COMMITTED TO SAVING ENERGY

OPERATING AND MAINTENANCE MANUAL

A Protec Cooling Tower is manufactured for optimum performance and the least maintenance possible in mind.

Protec Cooling Towers are anti-corrosive and offer long-life, yet it is very important that a regular maintenance schedule is followed. A maintenance schedule guarantees optimal performance keeping energy-efficiency throughout the entire system.

All instructions must be followed for our limited warranty to be valid.

PLEASE REVIEW THE FOLLOWING NOTES:

We are not responsible for any down time caused by any failure of our equipment. If our equipment is used as part of a critical process, you must take precautions, such as spare parts or spare equipment, to minimize down time.

Installation and wiring should be as per National and Local Codes.

Use precautions to avoid personal or property damage.

Before reaching into the top of the tower, always disconnect the fan motor.

WARNING

WATER TREATMENT MUST BE SUPPLIED AND/OR APPLIED BY A PROFESSIONAL IN THE FIELD IN ORDER TO AVOID FILL DAMAGE. IT IS THE USER'S/OWNER'S RESPONSIBILITY TO TREAT THE WATER IN ORDER TO STOP BIOLOGICAL CONTAMINANTS AND AVOID, AMONG OTHER BACTERIUM, THE LEGIONNELLA BACTERIA, WHICH IS KNOWN TO CAUSE LEGIONNAIRE'S DISEASE.

PREPARATION FOR START-UP:

CLEANING: Before adding water, the basin should be cleaned using a hose and/or a brush and drained to flush out any debris left over during the assembly process.

FILL UP: Fill the water basin up to 11/2" below the overflow intake and adjust the float valve to maintain said level.

NOTE: The tower should be at the highest point of installation. When the pump is started, make sure the water level is maintained by the make-up valve. Before reaching into the top of the tower, always disconnect the fan motor.

WATER DISTRIBUTION: Turn the water distribution pipes by hand, to make sure that they can rotate freely. Make sure there is no dirt inside the distribution header or pipes.

When steady flow is accomplished, check the distribution pipes rotation as per Illustration No. 1 on this page.

Check that the water is distributed evenly over the full surface of the fill.

MANUAL FAN TEST:

- 1) Spin fan by hand to insure proper installation and alignment, being properly fastened observe that the blades are not making contact with any internal parts of the tower (casing).
- 2) Check the motor wiring. The electrical rating has to agree with the plate on the cooling tower and on the motor.
- 3) For fan assemblies with belts or gears (Motor 7.5 h.p. and larger) star-delta or soft start starter is recommended to extend the life of the drive.
- 4) Check for loose nuts and bolts especially at the motor mountings.
- 5) Run the fan momentarily to check the rotation, which should be clockwise when viewed from above.
- 6) Run the fan for two to three hours to check that no vibration develops.

IMPORTANT NOTE: If the tower has not been in operation for more than three months check the insulation of the motor with 500V Megger Insulation Tester, the reading should be 1 Megaohm or above. If it is less, the motor should be opened for inspection and must be dried to avoid short circuiting.

Chart No. 1:

Distribution pipes rotation speed.


MODEL PCT	8-30	40-60	80-250	300-350	400-700	800-1000
RPM	7-12	5-8	5-7	3.5-5	2.5-4	2-3

Chart No. 1 Notes:

- 1) Rotation speed must be within these values. Even though, there are designed for larger RPM, in order to avoid damage of the bearings do not exceed these values.
- 2) The distribution openings must be located under the pipe and should be between 0° and 5° to the vertical. See Illus. No. 1 on this page.
- 3) The rotation speed is increased by increasing the angle to the vertical and decreased by decreasing the same. See Illus. No.1.
- 4) Rotation should be clockwise when viewed from above.

SPRINKLER PIPE END VIEW A-A

(VIEWED THROUGH INSPECTION WINDOW)



ILLUS. NO. 1


MAINTENANCE:

WATER DISTRIBUTION SYSTEM: DISTRIBUTION HEADER:

If the water distribution system's rotation slows down or stops, first check whether the water circulation rate is normal. If so, then the distribution header should be checked for dirt. **Before reaching into the top of the tower, always disconnect the fan motor.**

- a) For models PCT-8 through PCT-80 refer to Illus. No. 2 on this page.
 - 1) Remove the threaded cap (1).
 - 2) Remove the nut (2) and the washer (3), then lift off the top section (6).
 - 3) Clean parts with water. (Do not use acid PH less than 3).
- b) For models PCT-100 through PCT-1000 refer to Illus. No. 3 on this page.
 - 1) Remove the threaded cap (1) and take the nut (2) off.
 - 2) Pull the rotary parts off from the fixed section. (This will allow checking for any dirt.)
 - 3) To replace the lower bearing (6) or oil seal (7), unscrew (4) and (10).
 - 4) To reassemble, follow the same steps, but in reverse.

THIS DATA IS SUBJECT TO CHANGE WITHOUT NOTICE



ILLUS. NO. 2

IMPORTANT NOTE:

- 1) When passing the oil seal (7) over the center pole (5), avoid damage to the lips of the oil seal.
- 2) The oil seal should be replaced every 2 to 3 years.
- 3) When replacing the sprinkler head bearings, pack them adequately with grease.

DISTRIBUTION PIPES:

Cleaning of the distribution pipes is performed as follows:

- 1) Mark the original position before removing any of the distribution pipes. The distribution openings should be under the pipe at 0°-5° to the vertical.
- 2) For model PCT-8 through PCT-80 slacken the distribution pipe lock nuts, then unscrew the pipe and remove it to be flushed.
- 3) For models PCT-100 through PCT-1000 unscrew the cap at the end of the pipe and let the water from the distribution header flush it.

CASING:

If the casing becomes soiled, wash it with soap and water.

BASIN:


Inspect the water basin for accumulated dirt, when necessary scrub and flush through the drain, regularly clean the strainer located inside the basin. (Please refer to maintenance schedule).

FILL:

When the proper water treatment is performed our fill material will not deteriorate. Inspect it as indicated in our maintenance schedule.

WARNING:

WATER TREATMENT MUST BE SUPPLIED AND/OR APPLIED BY A PROFESSIONAL IN THE FIELD IN ORDER TO AVOID FILL DAMAGE. IT IS THE USER'S/OWNER'S RESPONSIBILITY TO TREAT THE WATER IN ORDER TO STOP BIOLOGICAL CONTAMINANTS AND AVOID, AMONG OTHER BACTERIUM, THE LEGIONNELLA BACTERIA, WHICH IS KNOWN TO CAUSE LEGIONNAIRE'S DISEASE.



ILLUS. NO. 3

NOTE:

It is recommended to wear eye protection at all times when viewing or inspecting any cooling tower performance from the top. When working on our cooling towers you should be protected complying with OSHA requirements.

Do not stand or walk directly on the fill. Always place hard cardboard or plywood on the fill to distribute the load and avoid damage.

Before reaching into the top of the tower, always disconnect the fan motor.

SPEED REDUCER:

- 1) PCT-8 thru PCT-200 are direct driven and **Illus. No. 4 and No. 5** should be ignored.
- 2) Belt Drive - Model PCT-250 through PCT-500 are standard with belt drive and optional with gear drive.
- 3) Gear Drive - Model PCT-250 through PCT-500 are optional with gear drive, Model PCT-600 through PCT-1000 are standard with gear drive.

Before reaching into the top of the tower, always disconnect the fan motor.

Spin the fan by hand to see if it rotates freely and smoothly.

*Gear Box Speed Reducer.


Before start-up, fill gear box with oil as indicated below. Motor can not be started if gear drive is not full of oil.

Recommended Oil: SAE 90

Capacity: 0.5 Gallons

Note: After the first 100 hours of operation the oil should be changed. After that, refer to the maintenance schedule.

GEAR SPEED REDUCER



SPEED REDUCER

- 01- GEAR CASING
- 02- GEAR COVER
- 05- DRIVEN SHAFT
- 06- DRIVEN WHEEL
- 07- INTERMEDIATE PINION
- 08- INTERMEDIATE WHEEL
- 10- DRIVING PINION
- 14- BEARING (EXTERIOR)
- 15- BEARING (INTERIOR)
- 16- BEARING
- 17- BEARING
- 25- TRANSMISSION FLANGE
- 26- SHAFT SEAL

BEARING BOX

- 101- CASING
- 102- POWER SHAFT
- 103- BEARING (TOP)
- 104- BEARING (BOTTOM)
- 105- SHAFT SEAL
- 106- STEEL PLATE COVER

MOTOR


- 201- SHAFT

ILLUS. NO. 4

GEAR BOX COMPONENTS

THIS DATA IS SUBJECT TO CHANGE WITHOUT NOTICE

CROSS - SECTION BEARING BOX



ILLUS. NO. 5

CHART No. 2

V-BELT DRIVE SPECIFICATIONS

MODEL	MOTOR		MOTOR SIDE		FAN SIDE		VEE-BELT TYPE	VEE-BELT QTY	RPM	BEARING No.	
	HP	POLE	PULLEY	SHAFT	PULLEY	SHAFT				TOP & BOTTOM	
PCT-250	7 1/2	4	5"	32mm	20"	38mm	B-94"	3	410	6212	
PCT-300	10	4	5"	32mm	20"	38mm	B-94"	3	410	6212	
PCT-350	10	4	5"	32mm	20"	38mm	B-94"	3	410	6212	
PCT-400	15	4	5"	42mm	24"	50mm	B-102"	4	340	6312	
PCT-500	15	4	5"	42mm	24"	50mm	B-102"	4	340	6312	

CHART No. 3 MOTOR AND DRIVES RPM

MODEL	MOTOR		BELTS RPM	GEARS RPM
	PCT	HP		
8-10		1/4	1200	N/A
15-20		1/2	1200	N/A
30		1	1200	N/A
40-50		2	1200	N/A
60-80		2	900	N/A
100-150		3	900	N/A
175-200		5	720	N/A
250		7.5	1800	410
300-350		10	1800	410
400-500		15	1800	340
600-700		20	1800	N/A
800-1000		30	1800	N/A

The above data is suitable for 60-HZ operation only.

CHART No. 4 WATER DISTRIBUTION HEADER BEARINGS

COOLING TOWER MODEL	BEARING No.	TOP	BOTTOM
PCT - 60 & 80		77R10	77R10
PCT - 100 & 125		6301ZZ	6003ZZ
PCT - 150, 175, 200, 250, 300, 350, & 400		6303ZZ	6004ZZ
PCT - 500, 600 & 700		6205ZZ	6206ZZ
PCT - 800 & 1000		6206ZZ	6009ZZ

THIS DATA IS SUBJECT TO CHANGE WITHOUT NOTICE

MAINTENANCE SCHEDULE

	Fan	Motor	Speed Reducer	Fan Shaft Bearings	Eliminators	PVC Fill	Water Basin	Sprinkler System	Structural Members	FRP Casing	Float Valve	Bleed Rate	Drive Shaft	Flow Control Valves	Suction Screen
1. Inspect for clogging					W	W		W							W
2. Check for unusual noise or vibration	D	D	D						Y				D		
3. Inspect keys and set screws		S	S	S									S		
4. Lubricate		Q		Q											
5. Check oil seals			S												
6. Check oil level			W												
7. Check oil for water and dirt			M												
8. Change oil (at least)			S												
9. Check water level/quality							D								
10. Check flow rate												M			
11. Check for leakage							S	S			S				
12. Inspect general condition					Y	Y	Y		S	Y	Y		S	S	
13. Tighten loose belts	S	S	S	S					Y	R			S		
14. Clean	R	S	R		R	R	S	R			R		R	R	W
15. Repaint		R	R												
16. Completely open and close														S	

D – daily; W – weekly; M – monthly; Q – quarterly; S – semi-annually; Y – yearly; R – as required.

THIS DATA IS SUBJECT TO CHANGE WITHOUT NOTICE

TROUBLE ANALYSIS TABLE


TROUBLE	CAUSES	ADJUSTMENT
Rise in Cooling Water Temperature	<ol style="list-style-type: none"> 1. Excessive or inadequate cooling water flow 2. Irregular flow of air 3. Short circuiting of air from tower outlet 4. Irregular rotation of distribution pipes 5. Improper flow of air 6. Blocking of the fill 7. Slackened or severed belt 	<ol style="list-style-type: none"> 1. Adjust to the specified flow 2. Improve Ventilation 3. Improve Ventilation 4. Remove dirt and scale 5. Adjust the angle of fan blades 6. Clean the blocked area 7. Adjust or replace belts
Abnormal Water Flow	<ol style="list-style-type: none"> 1. Blocking of the distribution pipe openings. 2. Blocking of strainer mesh 3. Blocking in fill 4. Water level decrease in the water basin 5. Improper selection of water pump 	<ol style="list-style-type: none"> 1. Clean distribution pipes 2. Remove strainer and clean 3. Adjust float valve or quick water make up system 4. Replace pump with proper size pump 5. Clean fill or replace
Noise and Vibration	<ol style="list-style-type: none"> 1. Fan blade tips touching casing 2. Bending of fan shaft 3. Loose bolts 4. Motor's bearing damaged 5. Damage in fan and / or motor 6. Speed reducer bearings problems and / or oil not enough (When applicable) 	<ol style="list-style-type: none"> 1. Adjust fan mounting 2. Adjust at specialized shop 3. Tighten loose bolts 4. Repair or replace motor 5. Replace fan 6. Check bearings and / or oil level
Excessive Current	<ol style="list-style-type: none"> 1. Drop in voltage 2. Fan blades pitch angle of the fan blades 3. Motor damaged 4. Overload due to excessive air flow 	<ol style="list-style-type: none"> 1. Check supply voltage 2. Adjust fan blade angle 3. Repair or replace motor 4. Adjust fan blades angle
Water Carry Over	<ol style="list-style-type: none"> 1. Irregular rotation of distribution pipes 2. Blocking of the fill 3. Improper installation of eliminator 4. Excessive circulating water 5. Excessive air flow 	<ol style="list-style-type: none"> 1. Adjust the angle of the distribution pipes and check the distribution header 2. Eliminate blockage at fill 3. Improve & repair eliminator 4. Adjust water flow 5. Adjust fan blades angle

THIS DATA IS SUBJECT TO CHANGE WITHOUT NOTICE

BELT ADJUSTMENT AND REPLACEMENT PROCESS

BELT ADJUSTMENT

Belt tension must be checked before starting motor and if adjustments are needed tighten tension bolts as shown on **Illus. No. 8**.




ILLUS. NO. 6

AFTER AND DURING OPERATION

Make the first inspection within one or two days of full operation after start-up. Make necessary adjustments since belts may stretch a little after the initial start-up.

Make sure before reaching into the top of the tower to always disconnect the fan motor.




ILLUS. NO. 7


BELT REPLACEMENT

Refer to Illustrations 8 & 9 for belt replacement:

- A - Loosen slide bolt and nuts (4 pcs).
- B - Loosen tension nuts (2 pcs) and slide motor toward the center. Remove the old belts.
- C - Hook the new belts to the grooves of both motor and fan side pulley.
- D - After new belts are in place adjust it within the framework of permissible tension.
- E - Tightening bolts and nuts is the reverse of loosening. Change all belts simultaneously. Do not mix new and old belts. (**Illus. No. 9**).
- F - After new belts have been installed repeat the process of adjustment found under the "**After and During Operation**" heading on this page.



ILLUS. NO. 8



ILLUS. NO. 9

THIS DATA IS SUBJECT TO CHANGE WITHOUT NOTICE



PROTEC® COOLING TOWERS, INC.

6935 N.W. 50th STREET • MIAMI, FLORIDA 33166 • TEL.: (305) 594-3684 • FAX: (305) 477-2514